


ASSEMBLY INSTRUCTIONS



ASSEMBLY TIPS

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to ensure fast and easy assembly.

Warning!

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishment.

HARDWARE LIST

1	JCBC M6 x 80mm	6 PCS	7	BARREL NUT M6 x 13mm	26 PCS
2	JCBC M6 x 60mm	20 PCS	8	ALLEN KEY M4	1 PC
3	JCBC M6 x 35mm	28 PCS			
4	JCBC-W M6 x 30mm	16 PCS			
5	WOOD SCREW 4.0 x 30mm	44 PCS			
6	WOOD DOWEL Ø10 x 30mm	26 PCS			

COMPONENT LIST

A	FRAME LEG - LEFT	1 PC	H	SIDE RAIL (LOWER REAR)	1 PC
B	FRAME LEG - LEFT	1 PC	I	SIDE RAIL (UPPER FRONT)	1 PC
C	HEADBOARD FRAME - UPPER	1 PC	J	SIDE RAIL (UPPER REAR)	2 SETS
D	FOOTBOARD FRAME - UPPER	1 PC	K	SLAT	1 PC
E	HEADBOARD FRAME - LOWER	1 PC	L	LEFT LADDER RAIL	1 PC
F	FOOTBOARD FRAME - LOWER	1 PC	M	RIGHT LADDER RAIL	3 PCS
G	SIDE RAIL (LOWER FRONT)	1 PC	N	LADDER STRETCHER	2 PCS
			O	RIGHT LADDER RAIL	1 PC

